


Identification	Part No.	Drawing	Dimensions in mm
HARTING crimping tool with locator for Han D®, Han E®, Han® C	<b>09 99 000 0110</b>	Wire gauge 0.5 - 4 mm <sup>2</sup>	
HARTING-Service crimping tool with locator	<b>09 99 000 0021</b>	Wire gauge 0.5 - 2.5 mm <sup>2</sup>	
BUCHANAN- crimping tool	<b>09 99 000 0001</b>	Wire gauge 0.5 - 4 mm <sup>2</sup>	   order separately
Locator	<b>09 99 000 0310</b>		
Crimping tool depth adjustment gauge	<b>09 99 000 0203</b> <b>09 99 000 0125</b> <b>09 99 000 0007</b> <b>09 99 000 0008</b> <b>09 99 000 0006</b>	Wire gauge 0,14 - 0,25 mm <sup>2</sup> ø 1,00 0,37 mm <sup>2</sup> ø 1,30 0,5 - 1 mm <sup>2</sup> ø 1,55 1,5 - 2,5 mm <sup>2</sup> ø 1,80 4 mm <sup>2</sup> ø 2,00	
HARTING- pneumatic crimping tool	<b>09 99 000 0314</b>	Wire gauge 0.14 - 0.25 mm <sup>2</sup> ø 1.00 0.37 mm <sup>2</sup> ø 1.30 0.5 - 1 mm <sup>2</sup> ø 1.55 1.5 - 2.5 mm <sup>2</sup> ø 1.80 4 mm <sup>2</sup> ø 2.00	   order separately
Locator	<b>09 99 000 0310</b>		
Crimping tool depth adjustment gauge	<b>09 99 000 0203</b> <b>09 99 000 0125</b> <b>09 99 000 0007</b> <b>09 99 000 0008</b> <b>09 99 000 0006</b>		
Table fixing and foot switch for pneumatic crimping tool	<b>09 99 000 0309</b>		
Insertion tool for crimp contacts	<b>09 99 000 0059</b>		For crimp contacts wires of less than 0.75 mm <sup>2</sup> it is recommended that an insertion tool is used. Contacts should be inserted from the wiring side and pushed down until a positive locking is achieved.
Removal tool for Han® ES inserts	<b>09 99 000 0367</b>		
Crimp contact removal for Han® EE, Han® Q 5/0, Han® Q 8/0 Han E® and Han A®	<b>09 99 000 0319</b>		A removal tool is necessary if contacts are to be replaced in the insert. The tool is inserted from the wiring side until a stop is noticeable. The wire with the crimp contact can then be pulled out from the same side of the insert.