









hager







- (F) Porte pour coffret
- (GB) Door for enclosure
- (D) Tür für Verteiler
- (I) Porta per centralino
- (E) Puerto para caja
- (P) Portos caixas
- (S) Dörr för kapsling
- (NL) Deur voor kast




Notice d'instructions
User instructions
Bedienungsanleitung
Istruzioni d'impiego
Instrucciones de uso
Instruções
Bruksanvisning
Gebruiksaanwijzing

Gamma








GZ 05A



GZ 06A



GP...T

