

**34.066**

Adapter 3.5mm stereo plug  
to 6.35mm stereo jack.

**34.257**

Adapter 6.35mm stereo plug  
to 3.5mm stereo jack.

**34.302****99.576** 1 x 34.302

Adapter 6.35mm mono plug  
to cinch jack.

**34.303**

Adapter 6.35mm mono plug  
to cinch jack. Metal handle.

**34.258****99.516** 1 x 34.258

Adapter 3.5mm stereo plug  
to 3.5mm stereo double jack.

**34.099**

Black

**34.044**

Red

**34.083**


Red

**34.045**

Black



Panel mounting cinch jack.  
Fixing hole Ø 6mm. Metal  
plated with black or red inside

**99.506**1 x 34.061 - 34.064  
34.044 - 34.045

Cinch plug and jack, red  
and black.

**34.061**

Black

**34.064**

Red

**99.505**2 x 34.061  
2 x 34.064

Cinch plug

**34.062**

Yellow

**34.063**

White



Cinch plug

**34.065**

Red

**34.197**

Black



Cinch plug, metal handle.  
With 2 red or black rings.  
For round cable Ø 5.3mm.

**34.314****99.517** 2 x 34.314

Adapter cinch jack to cinch  
jack.

**34.315****99.578** 1 x 34.315

Adapter cinch plug to double  
cinch jack.

**34.184****99.508** 4 x 34.184

DIN screw loudspeaker  
plug.

**34.209**

DIN screw loudspeaker jack.

**99.509**2 x 34.184  
2 x 34.209

2 DIN screw loudspeaker  
plugs + 2 DIN screw  
loudspeaker jacks.

**34.069**

Canon jack, chassis type, 3P.  
Metal.

**34.070**

Canon plug, chassis type,  
with push terminal 3P. Metal.

**34.071**

Canon jack, inline type, 3P.  
Metal handle.

**34.072**

Canon plug, inline type, 3P.  
Metal handle.

**34.089**

UHF coaxial cable connector  
for Ø 10mm cable.

**34.091**

UHF coaxial cord reducer for  
Ø 5.2mm cable. (for 34.089)

**34.090**

UHF coaxial adapter,  
double female.

**34.093**

BNC male connector (50Ω)  
to screw.