

## ➔ Referenties

### Normale schaal (I<sub>n</sub>) Uitwijking 90°

#### Rechtstreekse aansluiting



Kaliber	DIN 48x48 D48A90-A	DIN 72x72 D72A90-A	DIN 96x96 D96A90-A	ROTEX 72x72 R72A90-A	ROTEX 96x96 R96A90-A
	Referentie	Referentie	Referentie	Referentie	Referentie
0 - 5 A	192A 1200	192A 1300	192A 1400	192C 1300	192C 1400
0 - 10 A	192A 1201	192A 1301	192A 1401	192C 1301	192C 1401
0 - 15 A	192A 1202	192A 1302	192A 1402	192C 1302	192C 1402
0 - 25 A	192A 1203	192A 1303	192A 1403	192C 1303	192C 1403
0 - 40 A	192A 1204	192A 1304	192A 1404	192C 1304	192C 1404
0 - 60 A	192A 1205	192A 1305	192A 1405	192C 1305	192C 1405
0 - 75 A		192A 1317	192A 1417	192C 1317	192C 1417
0 - 80 A		192A 1318	192A 1418	192C 1318	192C 1418
0 - 100 A		192A 1310	192A 1410	192C 1310	192C 1410

#### Aansluiting op stroomtransfo 5 A

Kaliber	DIN 48x48 D48A90-A	DIN 72x72 D72A90-A	DIN 96x96 D96A90-A	ROTEX 72x72 R72A90-A	ROTEX 96x96 R96A90-A
	Referentie	Referentie	Referentie	Referentie	Referentie
0 - 5 A	192A 2200	192A 3300	192A 4400	192C 3300	192C 4400
0 - 10 A	192A 2201	192A 3301	192A 4401	192C 3301	192C 4401
0 - 15 A	192A 2202	192A 3302	192A 4402	192C 3302	192C 4402
0 - 20 A	192A 2235	192A 3335	192A 4435	192C 3335	192C 4435
0 - 25 A	192A 2203	192A 3303	192A 4403	192C 3303	192C 4403
0 - 30 A	192A 2236	192A 3336	192A 4436	192C 3336	192C 4436
0 - 40 A	192A 2204	192A 3304	192A 4404	192C 3304	192C 4404
0 - 50 A	192A 2222	192A 3322	192A 4422	192C 3322	192C 4422
0 - 60 A	192A 2205	192A 3305	192A 4405	192C 3305	192C 4405
0 - 75 A	192A 2223	192A 3323	192A 4423	192C 3323	192C 4423
0 - 100 A	192A 2206	192A 3306	192A 4406	192C 3306	192C 4406
0 - 125 A	192A 2224	192A 3324	192A 4424	192C 3324	192C 4424
0 - 150 A	192A 2207	192A 3307	192A 4407	192C 3307	192C 4407
0 - 200 A	192A 2220	192A 3320	192A 4420	192C 3320	192C 4420
0 - 250 A	192A 2208	192A 3308	192A 4408	192C 3308	192C 4408
0 - 300 A	192A 2221	192A 3321	192A 4421	192C 3321	192C 4421
0 - 400 A	192A 2209	192A 3309	192A 4409	192C 3309	192C 4409
0 - 500 A	192A 2225	192A 3325	192A 4425	192C 3325	192C 4425
0 - 600 A	192A 2210	192A 3310	192A 4410	192C 3310	192C 4410
0 - 750 A	192A 2230	192A 3330	192A 4430	192C 3330	192C 4430
0 - 800 A	192A 2226	192A 3326	192A 4426	192C 3326	192C 4426
0 - 1000 A	192A 2211	192A 3311	192A 4411	192C 3311	192C 4411
0 - 1200 A	192A 2227	192A 3327	192A 4427	192C 3327	192C 4427
0 - 1250 A	192A 2231	192A 3331	192A 4431	192C 3331	192C 4431
0 - 1500 A	192A 2212	192A 3312	192A 4412	192C 3312	192C 4412
0 - 2000 A	192A 2228	192A 3328	192A 4428	192C 3328	192C 4428
0 - 2500 A	192A 2213	192A 3313	192A 4413	192C 3313	192C 4413
0 - 3000 A	192A 2229	192A 3329	192A 4429	192C 3329	192C 4429
0 - 4000 A	192A 2214	192A 3314	192A 4414	192C 3314	192C 4414

#### Toewijzing van toebehoren

	DIN 48x48 D48A90-A	DIN 72x72 D72A90-A	DIN 96x96 D96A90-A	ROTEX 72x72 R72A90-A	ROTEX 96x96 R96A90-A
	Referentie	Referentie	Referentie	Referentie	Referentie
Beschermkap voor klemmen		192Z 1000	192Z 1011		
2 kappen	192Z 1016	192Z 1016	192Z 1016	192Z 1016	192Z 1016
Bouten + Schroeven	179Z 5000	179Z 5010	179Z 5010	192Z 0021	192Z 0022
Afdichtingsring	192Z 0007	192Z 0008	192Z 0009	192Z 0011	192Z 0012
Vervangraampje	179Z 2000	179Z 2010	179Z 2020	179Z 2030	179Z 2040