
# Ultrasonic sensor UB2000-30GM-E5-V15



#### **Features**

- Switch output
- 5 different output functions can be set
- TEACH-IN input
- · Synchronisation options
- · Deactivation option
- Temperature compensation
- · Insensitive to compressed air

### **Dimensions**



# **Technical data**

General specifications

Sensing range Adjustment range

Standard target plate

Transducer frequency Response delay

Unusable area

80 ... 2000 mm 120 ... 2000 mm CE

0 ... 80 mm 100 mm x 100 mm approx. 180 kHz approx. 150 ms

Indicators/operating means LED green

permanent: Power-on flashing: TEACH-IN function object detected permanent: switching state switch output flashing: TEACH-IN function LED yellow

normal operation: "fault"
TEACH-IN function: no object detected LED red **Electrical specifications** 

Operating voltage 10 ... 30 V DC , ripple 10 %SS No-load supply current I<sub>0</sub>  $\leq$  50 mA

Input/Output Synchronisation bi-directional 0 level -U<sub>B</sub>...+1 V 1 level: +4 V...+U<sub>B</sub> input impedance: > 12 KOhm

synchronisation pulse:  $\geq 100~\mu s,$  synchronisation interpulse period:  $\geq 2~ms$ Synchronisation frequency Common mode operation

Multiplex operation  $\leq$  30/n Hz, n = number of sensors Input Input type

1 TEACH-IN input, operating range 1: -U<sub>B</sub> ... +1 V, operating range 2: +4 V ... +U<sub>B</sub> input impedance: > 4.7 k $\Omega$ ; TEACH-IN pulse:  $\geq$  1 s Output

Output type 1 switch output E5, pnp NO/NC, parameterisable Repeat accuracy Rated operational current I<sub>e</sub>  $\leq$  0,5 % of switching point 200 mA, short-circuit/overload protected

EN 60947-5-2

Voltage drop U<sub>d</sub> ≤ 2,5 V Switching frequency f ≤ 3,3 Hz

1 % of the set operating distance Range hysteresis H Temperature influence < 2 % of full-scale value

Standard conformity Standards

**Ambient conditions** -25 ... 70 °C (248 ... 343 K) Ambient temperature Storage temperature -40 ... 85 °C (233 ... 358 K)

Mechanical specifications Protection degree connector V15 (M12 x 1), 5 pin Connection Material

Pepperl+Fuchs Group • Tel.: Germany +49 621 776-0 • USA +1 330 4253555 • Singapore +65 67799091 • Internet http://www.pepperl-fuchs.com

Housing brass, nickel-plated, plastic components PBT Transducer epoxy resin/hollow glass sphere mixture; polyurethane foam Mass 140 g

# Electrical connection

#### Standard symbol/Connections: (version E5, pnp)

+ U<sub>B</sub> 1 (BN) 2 (WH) - Teaching input U 5 (GY) Synchronous 4 (BK) Switch output 3 (BU) **Ç** 

Core colours in accordance with EN 60947-5-2.

#### Connector V15



097969\_ENG.xml

2004-11-04

#### Model number

#### **Description of the sensor functions**

#### **Synchronisation**

The sensor features a synchronisation input for the suppression of mutual interference. If this input is not used, the sensor will operate using an internally generated clock rate. The synchronisation of multiple sensors can be realised as follows:

#### External synchronisation:

The sensor can be synchronised by the external application of a square wave voltage. A synchronisation pulse at the synchronisation input starts a measuring cycle. The pulse must have a duration greater than 100 µs. The measuring cycle starts with the falling edge of a synchronisation pulse. Two operating modes are available:

- Multiple sensors can be controlled by the same synchronisation signal. The sensors are synchronised
- 2. The synchronisation pulses are sent cyclically to individual sensors. The sensors operate in multiplex mode.

#### Internal synchronisation:

The synchronisation connections of up to 5 sensors capable of internal synchronisation are connected to one another. When power is applied, these sensors will operate in multiplex mode.

The state of the switch output will not change until the switching threshold has been exceeded five times as an average of the five measurements is determined internally. A low level > 1 s or an open synchronisation input will result in the normal operation of the sensor.

Synchronisation cannot be performed during TEACH-IN and vice versa. The sensors must be operated in an unsynchronised manner to teach the switching point.

A high level at the synchronisation input disables the sensor.

#### Note:

If the option for synchronisation is not used, the synchronisation input has to be connected to ground (0V) or the sensor has to be operated via a V1 cable connector (4-pin).

#### Adjusting the switching points

The ultrasonic sensor features an analogue output with two teachable evaluation limits. These are set by applying the supply voltage  $-U_B$  or  $+U_B$  to the TEACH-IN input. The supply voltage must be applied to the TEACH-IN input for at least 1 s. LEDs indicate whether the sensor has recognised the target during the TEACH-IN procedure. Evaluation limit A1 is taught with  $-U_B$ , A2 with  $+U_B$ . For simple setting the switching point and the output functions the programming unit UB-PROG2 can be used.

Five different output functions can be set:

- 1. Window mode, normally-open function
- 2. Window mode, normally-closed function
- 3. One switching point, normally-open function
- 4. One switching point, normally-closed function
- 5. Detection of object presence

#### **TEACH-IN** window mode, normally-open function

- Set target to near switching point
- TEACH-IN switching point A1 with -UR
- Set target to far switching point
- TEACH-IN switching point A2 with +UB

#### **TEACH-IN** window mode, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A2 with +U<sub>B</sub>
- Set target to far switching point
- TEACH-IN switching point A1 with -UB

#### TEACH-IN one switching point, normally-open function

- Set target to near switching point
- TEACH-IN switching point A2 with +UB
- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with -UB


#### TEACH-IN one switching point, normally-closed function

- Set target to near switching point
- TEACH-IN switching point A1 with -UB

# UB2000-30GM-E5-V15


# Characteristic curves/additional information

### Characteristic response curve



Curve 1: flat surface 100 mm x 100 mm Curve 2: round bar, Ø 25 mm

# Programmed switching output function



5. A1 -> ∞, A2 -> ∞: Detection of object presence Object detected: Switch output closed No object detected: Switch output open

#### **Accessories**

#### Mounting aid

BF30

BF30F

BF5-30

M-105

#### Sound deflectors

UVW90-M30 UVW90-K30

# **Programming Unit**

**UB-PROG2** 

#### Cable sockets \*)

V15-G-2M-PVC V15-W-2M-PUR

\*) For additional cable sockets see section "Accessories".

### UB2000-30GM-E5-V15

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A2 with +UB

# **TEACH-IN** detection of object presence

- Cover sensor with hand or remove all objects from sensing range
- TEACH-IN switching point A1 with - $U_{\rm B}$
- TEACH-IN switching point A2 with +UB

#### **Default setting**


A1: unusable area

A2: nominal sensing range

#### **LED Displays**

Displays in dependence on operating mode	Green LED	Red LED	Yellow LED
TEACH-IN switching point			
Object detected	flashes	off	flashes
No object detected	off	flashes	flashes
Object uncertain (TEACH-IN invalid)	off	flashes	off
Normal operation	on	off	switching state
Interference	off	flashes	previous state

#### **LED-Window**



#### **Mounting conditions**

If the sensor is installed in places where the operating temperature can fall below 0  $^{\circ}$ C, the BF30, BF30-F or BF 5-30 fixing clamp must be used.